

Isomate[®]-C TT Notch Applicator

Easy to make
applicator



How to Make Applicator

The C TT Notch Applicator is made by using a chop-saw with a masonry or steel cutting blade (1/8th inch wide). Cut 3/4" PVC coupling half-way through approximately 1/4" down from top. Attach coupling to PVC pipe and cut at appropriate length to apply C TT to upper portion of the tree canopy.

How to Apply C TT Dispenser

1. Insert C TT dispenser until it stops at notch in the middle of coupling.
2. Spread dispenser the length of the cut in the coupling.
3. Flip dispenser back over coupling to lock in position.



1



2



3

For more information please contact your local distributor or Pacific Biocontrol Corp. at www.pacificbiocontrol.com